

РЪКОВОДСТВО НА ПОТРЕБИТЕЛЯ



- ВМЕСТИМОСТ - 500 мл/ 5-7 чаши
- СВЕТИНЕН ИНДИКАТОР
- СВАЛЯЩА СЕ ТОПЛОИЗОЛИРАНА ДРЪЖКА
- ВЪРТЯЩА СЕ ОСНОВА НА 360°
- ТЯЛО ОТ НЕРЪЖДАЕМА СТОМАНА
- ЗАЩИТА ОТ ПРЕГРЯВАНЕ И КИПЕНЕ

Мощност: 600 W
Захранване:
220-240V, 50-60Hz

ПРЕДИ ДА ЗАПОЧНЕТЕ РАБОТА С УРЕДА, ПРОЧЕТЕТЕ ВНИМАТЕЛНО ТОВА РЪКОВОДСТВО НА ПОТРЕБИТЕЛЯ.

ПРАВИЛА ЗА БЕЗОПАСНОСТ

- Уверете се, че напрежението посочено на кафеварката съответства на напрежението на мрежата във вашият дом. Нашата компания не носи отговорност при несъответствие и гаранцията не покрива повреда от този тип.
 - Вашият уред е за домашна употреба. Не е подходящ за професионална употреба.
 - Пазете уреда далеч от деца.
 - Включете уреда към заземен контакт. С цел защита на вашият уред не използвайте удължители, предоставящи посредствено ток. При използване на удължители, не забравяйте да използвате заземен контакт, с площ на напречното сечение на кабела 0,75 mm²
 - Не поставяйте джезвето в близост до преки източници на топлина, като например нагревател или отоплителна печка.
 - Поставете вашият уред на стабилна и равна повърхност. Не го поставяйте в края на масата или плота.
 - Не оставяйте кабела да виси от масата или плота или да е в близост до други уреди.
 - Избягвайте действия, които могат да повредят кабела и щепсела на уреда. Не го носете държейки кабела, за да изключите нагревателя, дръжте щепсела и никога не дърпайте самия кабел.
 - Никога не използвайте вашият уред за други цели освен за тези за които е предназначен. Не работете с вашият уред ако има повреда в кабела или щепсела или някаква друга повреда. Не се опитвайте да поправите сами. Обърнете се към оторизиран сервиз на ЕЛЕКОМ.
 - Когато не използвате вашият уред или по време на почистване, изключете го от контакта и се уверете, че е изстинал преди почистване.
 - Използвайте джезвето само с неговата основа. Не го поставяйте на основа на каквито и да било други уреди.
 - Докато наливате вода в уреда, отместете горната част (каната) от захранващата основа
 - След като пригответе кафето, приберете вашият уред.
 - Може да използвате джезвето също като терно кана. В този случай, когато водата заври, изключете уреда като натиснете бутона, защото няма да се изключи автоматично.
 - Ако джезвето работи и няма вода вътре, системата за работа на сухо ще спре електричеството автоматично.
- В такъв случай оставете да изстине напълно преди да налеете вода отново.
- НИКОГА не потапяйте уреда във вода или други течности, не поставяйте в съдомиялна машина, не го използвайте в баня или други места, които има високо ниво на влага.
 - НИКОГА не оставяйте нагревателя влажен. Ако това се случи, преди да го включите и да започнете работа, подсушете го напълно.
 - Този уред не е предназначен за използване от хора (включително деца) с ограничени физически, сетивни или умствени способности, или липса на опит и познания, освен ако те не са били наблюдавани или инструктирани относно използването на уреда от лице, отговорно за тяхната безопасност
 - Децата трябва да бъдат надзиравани да не си играят с уреда.

1. За обслужване или ремонт в гаранция, моля свържете се с оторизиран сервиз на ЕЛЕКОМ, който е упоменат в гаранционната карта, която придружава продукта.

2. Не използвайте никога уреда, ако кабелът или щепсела са повредени, ако не работи нормално или е показал друга повреда. Не се опитвайте да разглобявате някоя част от уреда. Това трябва да се извършва само в оторизиран сервиз на ЕЛЕКОМ.

3. Неспазването на тези инструкции освобождават ЕЛЕКОМ от всяка отговорност за причинени щети и травми върху хора и животни.

4. В случай на манипулиране, ремонт или всяка модификация на уреда, направена от неквалифицирани лица или в случай на неправилна употреба, гаранцията ще бъде автоматично анулирана.

ОПИСАНИЕ НА УРЕДА

- 1 - Тяло/ кана на уреда
- 2 - Захранваща основа
- 3 - Сваляща се дръжка
- 4 - Копче Вкл./ Изкл.

- 5 - Светлинен Индикатор
- 6 - Захранващ кабел



РАБОТА С УРЕДА

- Разопакувайте внимателно уреда. Проверете дали всички части на уреда са налични.
- Отстранете всички части на опаковката (картони, пликчета и други).
- Огледайте внимателно уреда за видими транспортни или фабрични повреди.
- Огледайте захранващия кабел за нарушаване на изолацията му.
- Поставете уреда върху стабилна и равна повърхност. Не го поставяйте върху стъклени или върху фино обработени и лакирани дървени повърхности.
- Оставете достатъчно място около уреда - отгоре около 50см, отстрани по 5см отвсякъде.
- Поставете дръжката към джезвето.
- Измийте отвътре преди да използвате за първи път и след това налейте с вода. Изключете след като водата заври.
- Сипете вода и изчакайте вашият уред да се изстуди. Повреме на този процес, уверете се, че водата е на максимално ниво.
- След като водата заври, е възможно да остане котлен камък, в зависимост от твърдостта на водата. Това не е вредно за човешката здраве. Не използвайте джезвето без да има вода в него.
- Преди да използвате джезвето отново е необходимо да изчакате 15-20 секунди
- Напълнете джезвето според количеството вода, което желаете.
- Сложете джезвето върху основата.
- Когато включите джезвето, светлинният индикатор ще се включи и водата ще почне да загрева. Изключете джезвето когато водата заври - пусковият ключ на (0)

ПРИГОТВЯНЕ НА КАФЕ

- Може да пригответе кафе за 4-6 души.
- Сложете достатъчно количество студена вода в зависимост от броя чашки кафе (400мл за 4-6 души, максимум)
- Ако искате да пригответе средно-сладко кафе за 1 човек, сложете 1 чаша вода, 1 лъжичка захар, и 1 лъжичка турско кафе смляно.
- Поставете уреда върху основата, и включете с пусков ключ (I) .
- Когато кафето започне да се надига, изключете уреда и налейте малко кафе в чашките (за образуване на каймак)
- Поставете уреда отново върху основата, когато кипне отново може да си налееете.
- Може да пригответе кафето по ваш вкус.

АРТИКУЛ: КАФЕВАРКА

МОДЕЛ: ЕК-5040 SS



ПОЧИСТВАНЕ И ПОДДРЪЖКА

Преди почистване, изключете уреда. Изключете от контакта и изчакайте да изстине.

- Почистете външната част със суха и влажна кърпа.
- Никога не потапяйте уреда във вода, както и не го поставяйте за миене в съдомиялна машина.
- Избягвайте абразивни и химични почистващи препарати (белина, солна киселина и др.)

ПОЧИСТВАНЕ НА ЕЛЕКТРИЧЕСКАТА КАФЕВАРКА ОТ КОТЛЕН КАМЪК

- Премахването на котлен камък съдържащ в кафеварката, периодично е важно за хигиената и икономията на енергия.
- Котления камък, който съдържа използваната вода се натрупва и изгаря след това се образува кафяв слой върху отоплителната основа, който води до намаляване на ефективността на вашия уред.
- При по-светло образуване на котлен камък може по-лесно да се отстрани чрез миене.
(Не забравяйте да изключите уреда преди това)
- Може да използвате препарат за почистване на котлен камък или бял оцет за битова техника.
- За да почистите уреда с препарат, след като заври малко количество вода в кафеварката, прибавете препарата във врящата вода и разбъркайте. Изчакайте 2-3 минути да заври, след което излейте и изплакнете вътрешността 2-3 пъти с чиста вода.



Този символ означава, че продукта не трябва да се изхвърля заедно с останалите битови отпадъци, за да се избегне замърсяване на околната среда и нараняване на хора. Отнесете уреда в специализиран пункт за рециклиране на електроуреди.



Всички уреди с марка ЕЛЕКОМ отговарят на БДС!

ЕЛЕКОМ е регистрирана търговска марка за България с №48734 / 02.09.2004 г. от Българското патентно ведомство.
ЕЛЕКОМ е регистрирана търговска марка за Европа с №948329 / 2007- Женева на Световната организация за интелектуална собственост.

Артикул: Кафеварка; **Модел:** ЕК-5040 SS

Производител: Топ Троникс ООД; ЕИК 130985327

България; София, бул. Пемко Ю. Тодоров 4, Вх.А, п.к. 1

За контакти: 0885 438 232; 0885 439 220,

e-mail: elekom@elekom.bg,

www.elekom.bg

INSTRUCTION MANUAL



- CAPACITY: 500 ml / 5-7 CUPS
- FAST BOILING AND ANTI-OVERFLOW
- DETACHABLE HANDLE
- STAINLESS STEEL HOUSING
- ON/OFF SWITCH/ LIGHT INDICATOR
- 360° ROTATING BASE

Power: 600 W
Power Supply:
220-240V, 50-60Hz

BEFORE USING THIS PRODUCT, PLEASE READ THE OPERATING INSTRUCTION CAREFULLY!

ARTICLE: COFFEE MAKER

MODEL: EK-5040 SS



IMPORTANT SAFEGUARDS

Make sure that the voltage indicated on the Coffee pot corresponds with the mains voltage in your home. Our company shall not be held liable for any failures owing to any discrepancy and such failures shall not be covered by the guarantee.

This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments;
- Farm houses;
- By clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
- The instructions for appliances normally cleaned after use, and not intended to be immersed in water for cleaning, shall state that the appliance must not be immersed.
- Use your appliance for its intended purpose as recommended.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance must not be immersed.
- Keep the appliance and its cord out of reach of children aged less than 8 years.

Warning: Avoid spillage on the connector.

- The heating element surface is subject to residual heat after use.
- Since hot beverages such as coffee or milk may be boiled over, do not fill coffee machine with liquid more than maximum limit.
- Do not place your appliance over or near direct heat sources such as a stove, heating oven, etc.
- Ensure that the appliance is placed on a firm and flat surface. Do not put it on the edge of a table or bench. The least blow or knock may overturn it. Do not forget that it may be full of hot coffee.
- Do not let cord hang over edge of table or counter or touch any other appliances.
- Avoid actions that may harm or damage the cord or plug of your appliance. Do not carry your appliance by holding from the cord. To unplug the robot, hold the plug and NEVER pull by the cord.
- Never interfere with your appliance except for the purposes of cleaning and maintenance. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner, such as by dropping down, etc. Do not attempt to repair it by yourself. Refer immediately to an Authorized Service. Care that for using the only original spare parts.
- Always hold your appliance by its handle. Its outer surface may be hot.
- Unplug from outlet when not in use and before cleaning. Allow it to cool down completely before cleaning the appliance.

ADDITIONAL SAFETY ADVICES

- Use your appliance with its own power base unit only. Do not place on it those units belonging to any other appliance.
- When you have prepared your coffee, press on/off switch to turn the appliance off.
- Avoid contact with steam to be ejected from spout when the coffee is boiling, and do not let children to use the appliance.
- Do not fill above MAX level.
- Do not use your appliance in bathroom or any other places with a high rate of moisture.
- NEVER leave the power base unit and electrical connection ends of your appliance in a damp state. If they get wet, unplug before drying and do not operate the appliance before having it dried completely.

DESCRIPTION OF THE UNIT

- 1 - SS Kettle
- 2 - Power Supply Base
- 3 - Detachable handle
- 4 - On/ Off Button
- 5 - Indicator Light
- 6 - Cable



PREPARATION AND USE OF APPLIANCES

- Before using for the first time, clean the appliance and then fill water up to the MAX level. Turn off your appliance when the water starts boiling.
- **CAUTION:** When in use, the outer surface of your Coffee pot becomes heated; therefore you should not touch the hot surfaces. When preparing coffee, keep your hands away from the spout.
- The appliance must be switched off automatically or manually before attempting to lift the kettle from the power base unit.
- Do not use your coffee pot for any other purposes. Do not use any other liquids or solutions or the purpose of boiling.
- Besides coffee powder and water, NEVER fill in other powder or liquid.
- Use unboiled water, pure water.
- NEVER switch On the coffee pot if it is empty in coffee pot.

PREPARING TURKISH COFFEE

TIPS : Turkish coffee doesn't get filtered, it's important to grind the beans extremely finely.

- By using your Turkish Coffee pot you can prepare coffee for up to 4 persons.
- According to the number of cup of coffee, put sufficient quantity of cold water, Turkish coffee and sugar into your Turkish Coffee pot.
- Place the appliance onto the power base unit and switch on.
- At operation time mix your coffee continuously for mixing well.
- When the coffee starts bloating out, fill in 10-20ml of water into the coffee pot, foam disappeared immediately, keep switch On until to foam appear again, fill in 10-20ml of water into the coffee pot again and repeat 1-2 cycles, then pour the coffee to the cups.

SAFETY CUT-OFF DEVICE

- Protection against running dry: If your coffee pot ever runs dry while operating, a protection against running dry will cut off the power automatically.

CLEANING AND CARE

- Before cleaning turn off the on/off switch „0“ located on your coffee pot, unplug from outlet, and allow it to cool down.
- Discharge the water and remaining coffee from the appliance, and wipe the outside of it thoroughly with a dry or damp cloth.
- NEVER immerse the power base unit and the body into water, nor wash them in a dishwasher.

ARTICLE: COFFEE MAKER

MODEL: EK-5040 SS



- Avoid using abrasive and chemical cleaning agents (liquid bleach, hydrochloric acid, etc.) in cleaning any accessories of the appliance excepting of special cleaners.
- Removing the lime, composing in your water heater, periodically is important for hygiene and energy economy.
- Lime, contained in the used water, will accumulate and burn and then form a brown layer on the heating base, which will reduce the effectiveness of your appliance
- Light formation of lime can easily be removed by brushing (Do not forget to unplug the appliance before doing so).
- You can use lime removers or white vinegar for home appliances.
- To clean your appliance with a descaling agent: After you have boiled some quantity of water in your coffee maker, add the descaling agent into boiled water and mix them. After waiting for one moment, boil for 2-3 minutes more, empty the appliance, and rinse the inside of it 2-3 times with clean water repeatedly.
- To clean with white vinegar: Fill your appliance with white vinegar and wait for one hour. Then, pour the vinegar and rinse it 2-3 times repeatedly with clean water.
- To clean with citric acid: After you have boiled 200 ml. of water in your appliance, add 25 grams of citric acid and allow it to wait for 15 minutes. Then, empty the kettle and rinse it 2-3 times repeatedly with clean water. Repeat this process, if necessary. Always add water when using citric acid, and do not clean without water.



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



ELEKOM IS REGISTERED TRADE MARK FOR EUROPE WITH PATENT №948329/2007 -
GENEVA FROM WORLD INTELLECTUAL PROPERTY ORGANIZATION

ELEKOM IS REGISTERED TRADE MARK FOR BULGARIA WITH №48734/2004 FROM
BULGARIAN PATENT DEPARTMENT ORGANIZATION

Article: Coffee Maker; **Model:** EK-5040 SS

Manufacturer: Top Troniks LTD; VAT № 130985327

Bulgaria; Sofia, P. Y. Todorov Blvd., bl. 4, Ent. A, p.b. 1

Contacts: +359 088 566 70 15, **E-mail:**

e-mail: elekom@elekom.bg,

www.elekom.bg