



ИНСТРУКЦИЯ ЗА УПОТРЕБА

ТРИМЕР

МОДЕЛ: ЕК-0155



СЪС ЗАХРАНВАЩ АДАПТЕР
220-240V / 50-60HZ

ПРЕДИ ДА ЗАПОЧНЕТЕ РАБОТА С УРЕДА, ПРОЧЕТЕТЕ ВНИМАТЕЛНО ТОВА РЪКОВОДСТВО НА ПОТРЕБИТЕЛЯ.

ТРИМЕР ЗА ПОДСТРИГВАНЕ НА КОСМИ В НОСА И УШИТЕ

Благодарим Ви, че закупихте тримера за подстригване на косми в носа и ушите Елеком. Преди да използвате тази инструкция внимателно я прочетете и я запазете за бъдещи справки.

ПРЕДПАЗНИ МЕРКИ

1. Моля, обърнете внимание, че космите трябва да се подрязват внимателно.
2. За да избегнете нараняване на тъпанчето и носната лигавица, не поставяйте въртящата се глава дълбоко в носа и ушите, и не трябва да е по-дълбоко от 0,5 см. Използвайте приставките за тримера внимателно и поотделно.
3. Този продукт може да се използва само за подстригване на косми в носа, ушите, веждите, бакенбардите и за бръснене на мустаците. Той не може да бъде използван за други цели.
4. Моля, не го използвайте, ако уредът или острието са повредени.
5. За да избегнете ненужни наранявания, моля, не поставяйте уреда на място, на което могат да стигнат до него деца и недееспособни лица.

6. Изключете уреда, преди да извадите, смените или почистите острието.
7. Уверете се, че острието е монтирано правилно преди да го включите и моля, не включвайте уреда преди да поставите острието.
8. След употреба, изключете го, покрийте го със защитно покритие и го оставете на сухо място.
9. Ако хранващият кабел е повреден, той трябва да бъде заменен със специален хранващ кабел или специализирани компоненти, закупени от производителя или от сервиза за поддръжка.
10. Уредът не може да бъде потапян във вода, в противен случай може да се развали.
11. Моля, изключете зарядното устройство преди да го почистите и измийте дръжката след като изключите хранващия кабел.

ПОЧИСТВАНЕ И ПОДДРЪЖКА

1. Моля, изключете зарядното устройство, преди да го почистите, и измийте дръжката с вода след изключване на хранващия кабел.
2. Използвайте мека и леко влажна кърпа, за да извършете тялото на тримера.

Моля, не използвайте разреждател, бензин, алкохол или други химикали.

3. За да почистете острието, го развийте, използвайте четчица за почистване, за да почистите остатъците от косъмчета. Изплакнете острието, ако има много остатъци от косъмчета и го поставете след изсушаване.
4. Препоръчва се почистване след всяко използване.

ИНСТРУКЦИИ

1. Свалете защитното капаче.
2. Проверете дали има деформация или повреда на острието преди употреба; моля, не използвайте, ако има повреди или деформации, може да навреди на кожата.
3. Повърхността на острието може леко да се загрее по време на употреба, но не оказва влияние върху употребата му.

ПОДСТРИГВАНЕ НА НОСНИТЕ КОСМИ

1. Носът трябва да е чист.
2. Внимателно вкарайте тримера в едната ноздра.
Моля, не поставяйте тримера в ноздрите си повече от 0,5 см.
3. Бавно завъртайте продукта, за да отрежете всички нежелани косъмчета в ноздрите си.



ПОДСТРИГВАНЕ НА КОСЪМЧЕТАТА В УШИТЕ

1. Ухото трябва да е чисто, без ушна кал.
2. Движете бавно тримера по ръба на ухото, за да подстрижете косъмчетата по ръба на ухото.
3. Внимателно вкарайте тримера в ушния канал. Моля, не поставяйте тримера в ушния канал повече от 0,5 см. В противен случай може да причини нараняване на тъпанчето.
4. Завъртайте бавно устройството, за да отрежете всички нежелани косъмчета в ухото.





Този символ означава, че продукта не трябва да се изхвърля заедно с останалите битови отпадъци, за да се избегне замърсяване на околната среда и нараняване на хора. Отнесете уреда в специализиран пункт за рециклиране на електроуреди.



Този уред не е подходящ за използване в бани или душ кабинни.



Всички уреди с марка ЕЛЕКОМ отговарят на БДС!

ЕЛЕКОМ е регистрирана търговска марка за България с №48734 / 02.09.2004 г. от Българското патентно ведомство.

ЕЛЕКОМ е регистрирана търговска марка за Европа с №948329 / 2007-Женева на Световната организация за интелектуална собственост.

Артикул: Тример; Модел: ЕК-0155

Вносител: Топ Троникс ООД,

София, ул. „П. Панайотов“ 12, магазин 26

За контакти: тел.: (02) 936 07 89; (02) 936 00 54; моб.: (088) 566 70 15,

e-mail: elekom.bg@abv.bg, website: www.elekom.bg



INSTRUCTION MANUAL

TRIMMER

MODEL: EK-0155



POWER ADAPTER
220-240V / 50-60HZ

BEFORE USING THIS PRODUCT, PLEASE READ THE OPERATING INSTRUCTION CAREFULLY!

NOSE & EAR HAIR TRIMMER

Thank you for purchasing ELEKOM nose & ear hair trimmer you should carefully read this instruction prior to use, and keep it for future reference.

PRECAUTIONS

1. Please note that trim the hair gently.
2. To avoid injuring the eardrums and the nose mucous membrane, do not insert the rotary head into the depth of noses and ears which should not deeper than 0.5 cm. Use the sideburns trimmer carefully and separately.
3. This product can only be used for trimming nose hair, ear hair, eyebrows, sideburns and mustache shaving; it cannot be used for other purposes.
4. Please do not use it, during the appliance or the blade is damaged.
5. For avoiding any unnecessary injure, please do not put the appliance on the place that children and incapacitated persons can touch.
6. Please turn the appliance off before remove, replace or clean the blade.

7. Make sure the blade is properly installed before turn it on, and please do not turn on the appliance before install the blade.
8. After using, turn it off, cover it with protective cover, and then keep it in a dry place.
9. If the power cord is damaged, it must be replaced with dedicated power code or specialized components bought from the manufacturer or maintenance department.
10. This product cannot be immersed in water, otherwise it may break down.
11. Please power off the nose trimmer before clean it, and wash the handle part with water after unplug h the power code.

CLEANING AND MAINTENANCE

1. Please power off the nose trimmer before clean it, and wash the handle part with water after unplug the power code.
2. Use the soft and slightly damp cloth to wipe the trimmer body; please do not use thinner, gasoline, alcohol or other chemicals.
3. To clean the blade, screw off the blade, use cleaning brush to clean the hair

4. Promptly clean up after every time use is recommended.

INSTRUCTIONS

1. Remove the protective cover.
2. Please check whether there is any deformation or damage on the blade before use; please do not use if there is any damage or deformation, it may harm the skin.
3. The surface of blade may be heated up slightly during use, but it does not affect performance.

TRIM NOSE HAIR

1. To ensure the nose is clean.
2. Carefully insert the trim part into one naris. Please do not insert the trim part into your nares more than 0.5 cm.
3. Slowly move the product around to trim all the unwanted hair in your nares.



TRIM EAR HAIR

1. To ensure the ear is clean, without earwax.
2. Slowly move the trim part along the ear edge to shave the hair on the ear edge.
3. Carefully insert the trim part into the ear canal. Please do not insert the trim part into your ear canal more than 0.5 cm; otherwise it may cause eardrum injury.
4. Slowly move the product around to trim all the unwanted hair in your ear.





This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

ELEKOM IS REGISTERED TRADE MARK FOR EUROPE WITH PATENT №948329/2007 -
GENEVA FROM WORLD INTELLECTUAL PROPERTY ORGANIZATION
ELEKOM IS REGISTERED TRADE MARK FOR BULGARIA WITH №48734/2004 FROM BULGARIAN
PATENT DEPARTMENT ORGANIZATION

Article: Trimmer; Model: EK-0155
Importer: Top Troniks LTD., Sofia, P. Panayotov Str., Store 26
Contacts: Tel.: +359 (02) 936 07 89; +359 (02) 936 00 54;
mobile: +359 (088) 566 70 15, e-mail: elekom.bg@abv.bg,
website: www.elekom.bg