

РЪКОВОДСТВО НА ПОТРЕБИТЕЛЯ

- ЛЕСНО ПОЧИСТВАНЕ
- ЕРГОНОМИЧЕН ДИЗАЙН



- БЕЗОПАСНОСТ ПРИ РАБОТА

ПРЕДИ ДА ЗАПОЧНЕТЕ РАБОТА С УРЕДА, ПРОЧЕТЕТЕ ВНИМАТЕЛНО ТОВА РЪКОВОДСТВО НА ПОТРЕБИТЕЛЯ.



- ПРЕЦИЗНО ОФОРМЯНЕ НА БРАДАТА И МУСТАЦИТЕ



- ТРИМЕР ЗА УШИ И НОС
- БАТЕРИЯ:
AA/LR6

ВНИМАНИЕ

Използвайте този уред само по предназначението му, както е описано в това ръководство.

Не използвайте този продукт, ако той не работи правилно, ако е бил повреден или потапян във вода.



Защитно
капаче



Почистваща
четка



Зарядно
устройство



Тример за
подстригване
и оформяне



Тример за
уши и нос

ПРЕДИ ДА ЗАПОЧНЕТЕ

Винаги сресвайте брадата и косата си с фин гребен преди да започнете да я подстригвате.

ПРИКРЕПВАНЕ И ОТСТРАНЯВАНЕ НА ГЛАВАТА

За да прикрепите или отстраните главата, натиснете бутона за освобождаване на уреда.

ГРИЖЕТЕ СЕ ЗА ВАШИЯ ТРИМЕР ПОЧИСТВАНЕ И ПОДДЪРЖАНЕ СЛЕД ВСЯКА УПОТРЕБА

1. Изключете тримера.
2. Внимателно измийте останалите косми / изплакнете гребена и главата за подстригване.

ПРЕДПАЗНИ МЕРКИ ЗА ПОЧИСТВАНЕ

Използвайте само олекотено масло или масло за шевни машини върху остриетата. Не използвайте груби или корозивни почистващи препарати върху устройството или остриетата.

Не потапяйте уреда във вода, тъй като може да възникне повреда.

Не измивайте целия уред, тъй като може да възникне повреда.

СЪХРАНЕНИЕ

Винаги съхранявайте уреда на място без влага. Не го съхранявайте при температура над 60° C (140° F).

ПОЧИСТВАНЕ

Уверете се, че тримера е изключен.
Натиснете бутона и освободете главата от корпуса на уреда.

Внимателно потупайте главата на тримера върху равна повърхност, за да премахнете частиците от косми, и почистете с четката за почистване.

Уверете се, че главата на тримера е суха и тогава включете устройството.

Никога не използвайте четката за почистване върху фолиото, тъй като може да възникне повреда.

Затворете бръснещия блок.

На равни интервали поставете капка смазка върху рамката/главата за бръснене.

ПРЕДУПРЕЖДЕНИЕ:

Частите, които трябва да бъдат монтирани, така, че да не попадат във вода.

Използвайте и съхранявайте продукта при температура между 15° С и 35° С.

Използвайте само частите, доставени с уреда.

Пазете този продукт далеч от деца.

Употребата на този уред от хора с намалени физически, сетивни или психически способности или липса на опит и познания може да причини опасности.

Лицата, отговорни за тяхната безопасност трябва да дават изрични инструкции или да контролират използването на уреда.

Моля, не забравяйте да смазвате остриетата на уреда след всяко използване.



Този символ означава, че продукта не трябва да се изхвърля заедно с останалите битови отпадъци, за да се избегне замърсяване на околната среда и нараняване на хора. Отнесете уреда в специализиран пункт за рециклиране на електроуреди.



Всички уреди с марка ЕЛЕКОМ отговарят на БДС!

ЕЛЕКОМ е регистрирана търговска марка за България с №48734 / 02.09.2004 г. от Българското патентно ведомство.

ЕЛЕКОМ е регистрирана търговска марка за Европа с №948329 / 2007-Женева на Световната организация за интелектуална собственост.

Артикул: Тример; **Модел:** ЕК-1210

Вносител: Топ Троникс ООД; ЕИК № 130985327
България; София, ул. П. Панайотов № 12, склад 26

За контакти: тел.: (02) 936 07 89; (02) 936 00 54;
моб.: (088) 566 70 15, e-mail: elekom.bg@abv.bg,

website: www.elekom.bg

TRIMMER
MODEL: EK-1210



INSTRUCTION MANUAL

- EASY TO CLEAN
- ERGONOMIC DESIGN

- TRIMS BEARD & MOUSTACHES PRECISELY
- NOSE & EAR TRIMMER



- SAFE AND HYGIENIC

- BATTERY: AA/LR6

**BEFORE USING THIS PRODUCT,
PLEASE READ THE OPERATING
INSTRUCTION CAREFULLY!**



CAUTION

Use this appliance only for its intended use as described in this manual.

Do not use this product if it is not working correctly, if it has been damaged, or dropped into water.



Protective
cap



Cleaning
brush



Charging
power supply



Trim & Modeling



Nose & Ear
Trimmer

HOW TO USE BEFORE YOU BEGIN

Always comb your beard and hair a fine comb before you start trimming.

ATTACHING AND REMOVING THE HEAD

To attach or remove the head press the release button of the product.

CARE FOR YOUR HAIR AND BEARD TRIMMER CLEANING AND MAINTAINING YOUR HAIR AND BEARD TRIMMER AFTER EACH USE

1. Turn the trimmer off.
2. Gently brush the remaining hairs away/
rinse from the guide comb and trimmer
blade.

CLEANING CAUTIONS

Only use the light-grade oil supplied or sewing machine oil on the blades.

Do not use harsh or corrosive cleaners on the units or their blades.

Do not submerging in water as damage will occur.

Do not wash the whole product as damage will occur.

CLEANING

Press the button and release the head assembly from the shaver body.

Gently tap the shaver head on a flat surface to remove the hair particles, and clean with the cleaning brush supplied.

Make sure the trimmer head dry and trun on the unit for use.

Never use the cleaning brush on the foils as damage may occur.

Close the shaving unit.

At regular intervals, put a drop of lubricant onto the shaving frame/head.

STORAGE

WARNING: The parts that have to be fixed must be installed so they cannot fall into water.

Use and store the product at a temperature between 15°C and 35°C.

Only use the parts supplied with the appliance. Keep this product out of reach of children. The use of this appliance by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge can give cause to hazards, persons responsible for their safety should give explicit instructions or supervise the use of the appliance.

Before use, please make sure to use and after five positions to force oil.

TRIMMER
MODEL: EK-1210



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.



ELEKOM IS REGISTERED TRADE MARK FOR EUROPE WITH PATENT №948329/2007 -
GENEVA FROM WORLD INTELLECTUAL PROPERTY ORGANIZATION
ELEKOM IS REGISTERED TRADE MARK FOR BULGARIA WITH №48734/2004 FROM
BULGARIAN PATENT DEPARTMENT ORGANIZATION

Article: Trimmer; **Model:** EK-1210
Importer: Top Troniks LTD; VAT № 130985327
Bulgaria; Sofia, P. Panayotov № 12, Store 26
Contacts: Tel.: +359 (02) 936 07 89; +359 (02) 936 00 54;
Mobile: +359 (088) 566 70 15, **E-mail:** elekom.bg@abv.bg,
Website: www.elekom.bg